



Installation of Cobalt Ground Effects:

General Notes:

Remove parts from the carton and unfold them. Urethane products have a memory: when the parts are placed in the sun or heated with a hair dryer or heat gun, they will return to their original shape.

Important: Do not remove double sided tape or red backing until final installation. Clean all surfaces of the car prior to adhering double sided tape.

*****Pre-fit all parts prior to painting. If drying painted parts in an oven, carefully support each piece evenly. Please read all instructions and pre-fit all parts prior to painting. The warmer the car surfaces & parts, the better adhesion you will have (Above 80* F) for best results.***

Remember if you have any questions please do not hesitate to call 951-894-7883

Front Facia & Rear Facia towers

1. Clean all areas of the vehicle where the bonding tape will be contacting the car. This process will determine how well the parts will adhere to the vehicle. Surfaces can be cleaned with alcohol or other types of polish & wax removers.
2. Next you will apply the adhesion promoter provided. Let dry for approximately 10 minutes. Do not remove all of the tape backing at one time. Starting from the end, remove about 1 foot at a time.

Rocker extensions

1. Follow instructions for facias in preparing the surfaces.
2. Use the 4 rivets per side to secure the Rocker to the Car. Rivets to be used on flange that fits under the door.



Grill Screens

1. Attach to the rear bumper cover with 6-½ "self tapping screws.



ATTENTION

THE FOLLOWING CONTAINS IMPORTANT INFORMATION REGARDING PAINTING OF THE URETHANE PIECES. IT IS IMPERATIVE THAT THESE STEPS BE FOLLOWED IN ORDER TO AVOID ANY PROBLEMS WITH THE PAINT. IF THESE INSTRUCTIONS ARE NOT FOLLOWED, YOU MAY EXPERIENCE PEELING, CHIPPING, AND BUBBLING OF THE PAINT.

PAINTING INSTRUCTIONS

1. All painted surfaces must be sanded with 150 grit paper. This is very important, as the primer needs a rough surface for adhesion.
2. Clean with wax and grease remover.
3. Prime with urethane primer with a flex additive.
4. Putty any pinholes.
5. Re-prime, if necessary.
6. Pre-fit parts to vehicle.
7. Hand sand with 320 grit sand paper.
8. Clean with wax and grease remover.
9. Paint-add flex additive to the paint.

